




Betrieb der Seilwinde im Fahrbetrieb nicht erlaubt!
 Operation of the winch in driving mode not allowed!
 Fonctionnement du treuil pendant la conduite n'est pas permis!
 Operar el cabrestante mientras se conduce no está permitido!
 Vinssiä ajon ei ole sallittua!
 Obsluha navijáku při jízdě není povoleno!
 Betjene vinsjen under kjøring ikke er tillatt!
 Använda vinsch under körning är inte tillåtet!



MONTAGEANLEITUNG ASSEMBLING INSTRUCTIONS

Maximal zulässige Zugkraft
 95 kg
 Maximum permitted tensile
 force 95 kg



60 Minuten



weight: ca. 7,0 kg


WINCH CONSOLE REAR (SPARE WHEEL)/SEILWINDENKONSOLE HECK (RESERVERAD)








- Artikel-Nr: 19R 5380







Wild Land Drivers GmbH
 Sportplatzstr. 4
 D-85635 Höhenkirchen b. München




E-Mail: info@wild-land-drivers.de
 Phone: +49 (0) 8 10 2 / 89 58-0



	M8x16; DIN 912 Zn	2x
	M6x30; DIN 933 Zn	2x
	Ø 6,4; DIN 125 Zn	2x







Betrieb der Seilwinde im Fahrbetrieb nicht erlaubt!
 Operation of the winch in driving mode not allowed!
 Fonctionnement du treuil pendant la conduite n'est pas permis!
 Operar el cabrestante mientras se conduce no está permitido!
 Vinssiä ajon ei ole sallittua!
 Obsluha navijáku při jízdě není povoleno!
 Betjene vinsjen under kjøring ikke er tillatt!
 Använda vinsch under körning är inte tillåtet!

Artikel-Nr:
19R5380

Revision 1: 23.04.2020



page/Seite 5